

EZ MOUNTAIN RUSTIC FURNITURE

Hickory Dining Table Assembly Guide Standard Legs

Required Tools:

- 1/2" Socket Wrench
-

Before you begin remove any packing materials and separate the pieces. You should have the following pieces:



1 - Table Top



4 - Legs
(5 Legs if the table has leafs)




8 - Nuts & Washers
(9 if the table has leafs)




Step 1: Flip the table top upside down. Place a blanket or some form of padding underneath of the top if placing on a hard surface.



Step 2: Place one leg at each corner and align the bolts with the holes on the bottom of the table.



Step 3: Place a washer and a nut on each bolt and tighten with a 1/2" socket wrench until snug.



Step 4: Tilt the table on its side, then lift it onto its feet.

